



INSTRUCTION MANUAL



WARNING!



FALL OR STRANGULATION
HAZZARD

ALWAYS STRAP CHILD
INTO CARRIER

DO NOT USE UNTIL CHILD
CAN SIT UPRIGHT

MINIMUM WEIGHT 7KG / 16LBS
MAXIMUM WEIGHT 18KG / 40 LBS

DO NOT PLACE CARRIER
ON ELEVATED SURFACES



Manufactured exclusively for Dromader
Europe sp.z o.o.

Imported by Dromader Europe sp. z o.o.
Krancowa 1 street, 43-300 Bielsko- Biala, PL
www.dromadereurope.com
office@dromadereurope.com +48 792524212

Tested to EN 13209-1:2022

MODEL NO.: DT001

Baby Backpack Carrier Instructions for Adjustment of Parent Section


PLEASE ENSURE YOU COMPLETE THIS SECTION OF THE SETUP FIRST

Step 1



Unclip the chest strap as shown in the image. You can adjust this strap for more room at the chest.

Step 2



Unclip the waist strap as shown in the image. You can adjust both straps here for more comfortable load bearing.




Step 3



You can adjust the width of the shoulder straps here.
Be sure to adjust the sides equally to maintain
a stable ride for your baby.


Step 4



You can adjust the length of the shoulder straps here.
You can use the lower set of buckles to further
reduce the length of the shoulder straps.




Step 5



You can use this Velcro strap to adjust the carry position of the backpack to suit the carrier.

Adjustment of child section

Step 1



Start by making the carrier stable. Loosen the straps highlighted in the image on both sides. Pull out the base legs until they 'click' into place.



Step 2



Open the chest clasp and spread out the Baby shoulder straps.


Step 3



Open the leg clasp and spread out the Baby leg strap.



Step 4



Place the Baby's legs in the highlighted gaps and stirrups, then clasp the buckles in steps 3 and 4 and tighten the attached straps. Then re-adjust the strap in step 1. Adjust straps to ensure comfort and safety of your Baby.

Attaching of the sunroof



Insert the sunroof into the slots provided. Hang the plastic carabiner in the loops provided.

General safety instructions

- This carrier is only suitable for the carrying of children by adults.
- Care should be taken when putting on or removing the carrier
- Do not use until the child can sit unaided.
- Do not leave the child unattended in this carrier
- The child must have a minimum weight of 7 kg. The back carrier is for a maximum weight of the child of 18 kg approved. With the self-weight of the back carrier, from 2 kg, results in a total weight of 20 kilograms.
- Always fasten the child with the safety belt according to these directions for use.
- Never place the backpack on high objects. or uneven surfaces (e.g. tables, chairs, etc.).
- Always fold out the stand before placing the carrier on the ground.
- When the child is in the carrier, it could be in a position higher than the carer. Care should therefore be taken to be aware of hazards; e.g. door frames, low branches of trees etc.

General safety instructions

- Keep in mind, that the child in the carrier can become tired and it is recommended to make frequent breaks.
- When using the carrier be aware of the following:
 - your balance may be affected due to the movement of the child in the back carrier and also the carer.
 - your balance may also be affected without the child in the back carrier.
 - take care when bending or leaning forward
- The back carrier is for the use of leisure activities such as. Walks, hikes, etc. suitable, but not for sports activities (jogging, cycling, etc);
 - take great care when using or removing the back carrier
- Be aware that the child in the carrier may suffer from the effect of the weather and temperature before you do.
- Avoid serious injury from falling or sliding out. Always use child retention system.
- Additional or replacement parts should only be obtained from the manufacturer or distributor.



Putting on the carrier

- **1** Loosen off shoulder straps using the shoulderstrap adjuster.
- **2** Crouch down and place the right arm through the right shoulder strap.
- **3** Use your right hand to swing the carrier around on to your back whilst still crouched, steadying the shoulder strap with your left.
- **4** Slowly stand. whilst holding right shoulder strap with right arm, put left arm through left shoulder strap. Tighten shoulder strap adjusters.
- **5** Fasten the hip belt and the chest strap and tighten until a comfortable fit is achieved.
- **6** Ready to go. Caution: Ensure all straps and fastenings are tight and secure before begin your journey.



Washing / Maintenance

- After each trip, be sure to clean out your carrier thoroughly.
- Clean Zippers often to prevent them from failing. Use mild soap, warm water and a soft brush.
- If your carrier is wet, hang it to dry before storing.
- When your carrier is not in use loosen all the straps.
- Clean your carrier if dirt, sweat, salt and stains have worked their way into fabrics, webbings or mesh.

